



SEGWAY


36 V Harici Batarya



CE.04.00.1266.00-B

Kullanım Kılavuzu

TR Lütfen aşağıdaki QR kodunu tarayın veya şu adresi ziyaret edin: <https://service.segway.com/us-en/> . Batarya şarjı, depolama, bakım ve diğer konularla ilgili önemli güvenlik bilgilerinin ek dil sürümlerine (İngilizce, İspanyolca, Çince, Rusça, Yidişçe, Bengalce, Korece, Haiti Kreyolu, İtalyanca, Arapça, Lehçe, Fransızca ve Urduca) erişebilirsiniz.




TR_İçindekiler

Hoş Geldiniz	02
Paket İçeriği	03
Şema	04
Kurulum ve Kullanım	04
Nasıl Şarj Edilir	07
Dikkat	08
Teknik Özellikler	09
İşaret Açıklamaları	10
Ticari Marka	10
AB UYGUNLUK BEYANI	11
Sertifikalar	12
Garanti	13

Hoş Geldiniz

Segway 36 V Harici Batarya, menzilinizi önemli ölçüde artırarak şarj endişesi olmadan daha uzun süre sürüş yapmanızı sağlar.




⚠ Not:

Harici batarya yalnızca araca takılıyken şarj edilebilir. Ayrı olarak ŞARJ ETMEYİN; aksi halde araçta yetersiz güç, su geçirmezlik özelliğinin bozulması vb. sorunlara yol açabilir.
Harici bataryayı kullanmadan önce ürün yazılımını en son sürüme güncelleyin.
Gösterilen görseller yalnızca açıklama amaçlıdır. Gerçek ürün farklılık gösterebilir.

Paket İçeriği

- ① Harici Batarya x1
- ② Sabitleme Keleççesi x2
- Aksesuarlar



①




②


- ③ M6*25 mm Aylan Başlı Silindir Vida x4
- ④ Düz Rondelali M4*16 mm Bombeli Başlı Vida x2
- ⑤ 5 mm (3/16") Aylan Anahtar x1
- ⑥ 2,5 mm (3/32") Aylan Anahtar x1
- ⑦ 3 mm (7/64") Aylan Anahtar x1
- ⑧ Tutma Kolu x1




①



②




③



④



⑤



⑥


TR

03

Şema

●Harici Batarya

- ① DC Konnektörü
- ② Şarj Portu
- ③ Batarya Seviye Göstergesi



Kurulum ve Kullanım





Kurulum videosunu
izlemek için
QR kodunu tarayın

●Kurulum

○ E3 & E3 Pro



Adım 1

Gövde borusunun orta kısmındaki 2 vidayı 3 mm (7/64") alıyan anahtarıyla sökün, ardından aracı katlayın.




Adım 2

Görselde gösterildiği gibi, harici bataryayı bir elinizle tutun ve gövde borusu boyunca kaydırarak bataryanın arkasındaki 2 kılavuz pimi gövde borusundaki 2 vida deliğine yerleştirin.




Adım 3

Görselde gösterildiği gibi, 4 adet M6 vidayı 5 mm (3/16") alıyan anahtarıyla sıkarak harici bataryayı kelepçeler üzerinden gövde borusuna sabitleyin.




Not: 4 vidayı sırayla ön sıkın; ardından dönüşümlü ve simetrik biçimde tamamen sıkın.

Adım 4
Aracın şarj portu kapağını açın, 2 vidayı 2,5 mm (3/32") alyan anahtarıyla sökün ve ardından şarj portunu çıkarın.



Adım 5
Harici bataryanın DC konnektörünü aracın şarj portuna takın, ardından 3 mm (7/64") alyan anahtarıyla yaylı rondelali 2 adet M4*16 mm bombeli başlı vidayı dönüşümlü olarak sıkın.
Not: Vidaları sıkmadan önce DC portunun tamamen takılı olduğundan emin olun.




Adım 6
Kurulumdan sonra aracı açın.




* Harici batarya doğru şekilde takıldıktan sonra, araç açıldığında gösterge panelindeki harici batarya simgesi yanar.

● Tutma Kolumun Montajı


Adım 1
Görselde gösterildiği gibi, harici bataryayı taktıktan sonra aracı açmadan önce iki kayışı belirtilen konumdan geçirin.



Adım 2
Kayışları gövde borusunun etrafına sarın; önce A yuvasından, ardından B yuvasından geçirin. Sonra kayışları çekerek gövde borusunu sıkıca sardığından emin olun.



Adım 3
Kalan kayışları Adım 1'e göre yeniden gövde borusunun etrafına sarın ve kurulumu tamamlamak için A yuvasına geçirin.



Nasıl Şarj Edilir



Kurulumdan sonraki ilk kullanımdan önce, harici batarya ve araç tamamen şarj olana kadar aşağıdaki talimatlara uygun şekilde şarj edin.

Harici batarya, aracın dahili bataryasının yerini alamaz! Dahili batarya seviyesi düşük olduğunda harici batarya önce onu otomatik olarak şarj etmeye başlar.

Yüksek sıcaklıkta uzun süre sürüş sonrasında batarya aşırı ısınabilir. Hızlanma, azami hız ve yokuş tırmanma performansı etkilenebilir.

Harici batarya seviyesi %10'un altına düştüğünde batarya seviye göstergesi kırmızı yanıp söner.

Not: Harici batarya yalnızca araca takılıyken şarj edilebilir. Aynı olarak ŞARJ ETMEYİN.

Aracın orijinal şarj cihazının DC konnektörünü harici bataryanın şarj portuna bağlayarak harici bataryayı ve aracı aynı anda şarj edin.
Not: Harici batarya şarj edilirken batarya seviye göstergesindeki dört LED sırayla yeşil yanar. Batarya tamamen şarj olduğunda dört LED'in tamamı yeşil yanar ve 5 dakika sonra söner.



Dikkat

- İkincil hücreleri veya bataryaları sökmeyin, açmayın ya da parçalamayın.
- Bataryaları çocukların erişemeyeceği yerde tutun. Çocukların batarya kullanımı gözetim altında olmalıdır. Küçük çocukları bataryalardan uzak tutun. Özellikle küçük parçaları küçük çocukların erişiminden uzak tutun.
- Bir hücre veya batarya yutulursa derhal tıbbi yardım alın.
- Hücreleri veya bataryaları ısıya ya da ateşe maruz bırakmayın. Doğrudan güneş ışığında saklamaktan kaçının.
- Hücre veya bataryayı kısa devre etmeyin. Hücreleri ya da bataryaları birbirlerini veya diğer metal nesneler tarafından kısa devre edilebilecekleri şekilde kutu veya çekmeceye gelişigüzel saklamayın.
- Kullanım için gerekli olana kadar hücreyi veya bataryayı orijinal ambalajından çıkarmayın.
- Hücreleri veya bataryaları mekanik darbeye maruz bırakmayın.
- Bir hücre sızdırsa sıvının cilt veya gözlerle temas etmesine izin vermeyin. Temas olursa etkilenen bölgeyi bol suyla iyice yıkayın ve tıbbi yardım alın.
- Ekipmanla kullanın için özel olarak verilen şarj cihazı dışında başka bir şarj cihazı kullanmayın.
- Hücre, batarya ve ekipman üzerindeki artı (+) ve eksi (-) işaretlerine dikkat edin ve doğru kullanımı sağlayın.
- Ekipmanla kullanılmak üzere tasarlanmamış hücre veya bataryaları kullanmayın.
- Bir cihaz içinde farklı üreticilerin hücrelerini veya farklı kapasite, boyut ya da türde hücreleri karıştırmayın.
- Her zaman cihaz üreticisinin ekipman için önerdiği bataryayı satın alın.
- Hücreleri ve bataryaları temiz ve kuru tutun.
- Kirilenmeleri halinde hücre veya batarya terminallerini temiz ve kuru bir bezle silin.
- İkincil hücreler ve bataryalar kullanımdan önce şarj edilmelidir. Her zaman doğru şarj cihazını kullanın ve uygun şarj talimatları için üreticinin talimatlarına veya ekipman kılavuzuna başvurun.
- Kullanılmadığında bataryayı uzun süre şarj cihazına bağlı bırakmayın.
- Uzun süreli depolamadan sonra maksimum performansı elde etmek için hücreleri veya bataryaları birkaç kez şarj edip deşarj etmek gerekebilir.
- Orijinal ürün talimatlarını veya Kullanım Kılavuzunu ilerde başvurmak üzere saklayın.
- Hücreyi veya bataryayı yalnızca tasarlandığı uygulamada kullanın.
- Araç -5°C ile 2°C (23°F ile 35,6°F) arasında çalıştırıldığında, düşük sıcaklık sınırlamaları nedeniyle dahili bataryanın tüketim oranı harici bataryanınkini aşabilir. Sıcaklık -5°C (23°F) altına düştüğünde harici batarya çalışmayı durdurur; araç ise normal şekilde çalışmaya devam eder (araç -10°C (14°F) sıcaklığa kadar düzgün çalışabilir). Kullanıcının işlem yapması gerekmez; sıcaklık yükseldiğinde harici batarya otomatik olarak normal çalışmasına döner.
- Kurulum sırasında güvenliği sağlayın, aletleri doğru kullanın, uygun güvenlik önlemlerini alın ve kurulumu kullanım kılavuzundaki talimatlara göre tamamlayın.
- Gerektiğinde resmi müşteri hizmetleriyle iletişime geçin.

Teknik Özellikler

Segway 36 V Harici Batarya	
Model	NZJF3605A(PH1105)
Uyumlu Şarj Cihazı Modelleri	NBW41D001D7D
Uyumlu Araç Modelleri	E3, E3 Pro
Ürün Boyutları	339.1 × 110.1 × 92.2 mm (13.35 × 4.33 × 3.63 inç)
Net Ağırlık	Yakl. 2.5 kg (5.5 lb)
Brüt Ağırlık	Yakl. 3.47 kg (7.65 lb)
Nominal Kapasite	5.1 Ah
Nominal Enerji	184 Wh
Nominal Gerilim	36 V
Şarj Sınır Gerilimi	42 V
Çalışma Sıcaklığı	-5°C—40°C (23°F—104°F)
Depolama Sıcaklığı	-20°C—50°C (-4°F—122°F)

Şarj Süresi

Araç Modeli	Şarj Ekipmanı	Şarj Süresi*
E3	Kutudan Çıkan Şarj Cihazı	Yakl. 9 sa
E3 Pro		Yakl. 10.5 sa

*Şarj süresi, aracın dahili bataryası ile harici bataryanın tamamen boş olduğu durumdan itibaren ölçülür.

Menzil Karşılaştırması*

Eco Modu

Model	Sürüm	Standart Menzil	Harici Batarya ile
E3	U sürümü	Yakl. 45 km (28 mil)	Yakl. 70 km (43.5 mil)
	E sürümü		
	D sürümü		
	APAC sürümü		
E3 Pro	U sürümü	Yakl. 55 km (34 mil)	Yakl. 80 km (49.7 mil)
	E sürümü		
	D sürümü		
	APAC sürümü		

Sport Modu			
Model Sürüm Standart Menzil Harici Batarya ile			
E3	U sürümü	Yakl. 20 km (12.5 mil)	Yakl. 33 km (20.5 mil)
	E sürümü	Yakl. 30 km (18.5 mil)	Yakl. 48 km (29.8 mil)
	D sürümü	Yakl. 37 km (23 mil)	Yakl. 57 km (35.4 mil)
	APAC sürümü	Yakl. 30 km (18.5 mil)	Yakl. 48 km (29.8 mil)
E3 Pro	U sürümü	Yakl. 28 km (17.5 mil)	Yakl. 41 km (25.5 mil)
	E sürümü	Yakl. 40 km (25 mil)	Yakl. 58 km (36 mil)
	D sürümü	Yakl. 47 km (29 mil)	Yakl. 67 km (41.6 mil)
	APAC sürümü	Yakl. 40 km (25 mil)	Yakl. 58 km (36 mil)
* Tam şarjlı yeni bir batarya, 75±5 kg (165±11 lb) yük, 25±5°C (77±9°F) ortam sıcaklığı, ≤3 m/s rüzgâr hızı ve 86-106 kPa atmosfer basıncıyla, düz asfalt yüzeyde Eco ve Sport modlarında tam gaz sürüş yapılarak; batarya tükenip araç artık çalıştırılmayana kadar test edilmiştir. * Menzili; yük, ortam sıcaklığı, yol koşulları, hız, lastik basıncı ve sürüş alışkanlıkları (hızlanma/yavaşlama sıklığı, enerji geri kazanım işlevinin etkinleştirilmesi vb.) dahil birçok etkene göre değişebilir. Gerçek menzili belirli sürüş koşullarına göre farklılık gösterir.			

İşaret Açıklamaları

	CE Sertifikası		UL sertifikası		Rusya'da GOST sertifikası
	Batarya geri dönüşümü (ABD için)		Tüm batarya ve aküler için ayrı toplama		

Ticari Marka

Segway ve Rider Design, Segway Inc.'in ticari markalarıdır; Ninebot, Ninebot (Beijing) Technology Co., Ltd.'nin ticari markasıdır. İlgili sahipler, bu kılavuzda belirtilen ticari markalarının haklarını saklı tutar. Baskı tarihinde Segway 36 V Harici Bataryanın tüm işlevlerine ilişkin açıklama ve talimatları dahil etmeye çalıştık. Ancak ürün özelliklerinin sürekli geliştirilmesi ve tasarım değişiklikleri nedeniyle ürününüz bu belgede gösterilenlerden biraz farklı olabilir.

AB UYGUNLUK BEYANI

Üretici
Ad: Ninebot (Changzhou) Tech Co., Ltd.
Adres: 16F-17F, Block A, Building 3, N0 18 Changwu Mid Rd, Wujin Dist., Changzhou, Jiangsu, China
E-posta adresi: support-eu@segway.eu.com

Yetkili Temsilci
Ad: Segway-Ninebot Europe
Adres: Dynamostraat 7, 1014 BN Amsterdam, Hollanda
E-posta adresi: support-eu@segway.eu.com

Beyan konusu
Batarya Kategorisi: Hafif ulaşım araçları bataryaları (LMT bataryaları)
Ürün adı: Li-IYON BATARYA PAKETİ
Tip/model: NZJF3605A
Seri numarası: Z06B x yyyy x yyyyyy
("x", O ve I hariç A-Z arasındaki herhangi bir harfi; "y", O ve I hariç A-Z arasındaki herhangi bir harfi veya 0-9 arasındaki herhangi bir rakamı ifade eder.)
Teknik Özellikler: 36 V, 5100 mAh
Etiket:



Bu Uygunluk Beyanı, üreticinin tek sorumluluğu altında düzenlenmiştir. Yukarıda açıklanan beyan konusu aşağıdaki AB düzenlemelerine uygundur: • AB Batarya Tüzüğü: (AB) 2023/1542

Bu düzenlemelere uygunluk, ürünün aşağıdaki uyumlaştırılmış standartlara ve/veya teknik şartnamelere uygunluğu gösterilerek değerlendirilmiştir:

EN 62133-2:2017+AMD1:2021

Adına ve hesabına imzalayan: Ninebot (Changzhou) Tech Co., Ltd.

Yer: Amsterdam, Hollanda

Tarih: 24 Ekim 2025

Ad: Andreina Marques

Görev: Ürün Uygunluk Müdürü

imza:

Andreina Marques



AB Yetkili Temsilcisi:
Segway-Ninebot Europe
Dynamostraat 7, 1014 BN Amsterdam, Hollanda.

Ninebot (Changzhou) Tech Co., Ltd., NZJF3605A(PH1105) ürün modelinin AB Batarya Tüzüğü (AB) 2023/1542 ile uyumlu olduğunu beyan eder.

Uygunluk beyanı şu adreste görüntülenebilir: www.segway.com

Sertifikalar

Elektrikli ve Elektronik Ekipmanlarda Belirli Tehlikeli Maddelerin Kullanımının Kısıtlanması Yönetmelikleri 2012
Ninebot (Changzhou) Tech Co., Ltd., parçalar (kablolar, kordonlar vb.) dahil ürünün tamamının Elektrikli ve Elektronik Ekipmanlarda Belirli Tehlikeli Maddelerin Kullanımının Kısıtlanması Yönetmelikleri 2012 gerekliliklerini karşıladığını beyan eder.

Kullanıcılar İçin Batarya Geri Dönüşüm Bilgileri



Bu sembol, kullanım ömrünü tamamlayan batarya ve akülerin ayrıştırılmamış belediye atıklarıyla karıştırılmaması gerektiğini belirtir. Katılımınız, batarya ve akülerin çevre ve insan sağlığı üzerindeki etkisini en aza indirme çalışmalarının önemli bir parçasıdır. Uygun geri dönüşüm için bu ürünü veya içerdği batarya/aküleri tedarikçinize ya da belirlenmiş bir toplama noktasına lade edebilirsiniz.

Bu ürünün doğru şekilde bertaraf edilmesi, değerli kaynakların korunmasına yardımcı olur ve uygunsuz atık işleminin insan sağlığı ve çevre üzerindeki oluşturableceği olumsuz etkileri önler.

Bu atığın yanlış bertaraf edilmesi, ulusal mevzuatınıza göre cezalara tabi olabilir.

Kullanılmış batarya ve aküler için ayrı toplama sistemleri bulunmaktadır.

Lütfen batarya ve aküleri yerel belediyenizin atık toplama/geri dönüşüm merkezinde doğru şekilde bertaraf edin.

Garanti

Doğrudan Segway resmi çevrim içi mağazasından ve yetkili kanallardan satın alınan Segway 36 V Harici Batarya için garanti hizmeti sunuyoruz. Her durumda garanti süresi, ürünü ilk satın alan tüketicinin satın alma tarihinden itibaren hesaplanır. Garanti süresinin başlangıç tarihini belirlemek için ilk tüketici satın alımına ait satış fişi gereklidir. Sınırlı Garanti ve Uyumsuzluk Çözüm Sözleşmesi hakkında daha fazla bilgi için bölgenizdeki resmi web sitemizi ziyaret edin.

BU SINIRLI GARANTİ, TÜKETİCİ OLARAK SAHİP OLABİLECEĞİNİZ YASAL HAKLARI HIÇBİR ŞEKİLDE ETKİLEMEZ VEYA SINIRLAMAZ

Müşteri Hizmetleri

Ürünle ilgili sorunlarda Segway çevrim içi müşteri hizmetleriyle iletişime geçin veya taleplerinizi e-posta ile gönderin; Segway destek personeli size yardımcı olacaktır.

Segway Çevrim İçi Hizmetler Bağlantısı: <https://service.segway.com/>

Müşteri Destek E-posta Adresi:

Amerika: technicalsupport@segway.com

ASYA-PASİFİK, ORTA DOĞU ve BDT: service@ninebot.com

Avrupa: support-eu@segway.eu.com



SEGWAY


36 V External Battery



CE.04.00.1266.00-B

User Manual

EN Please scan the QR code below or visit: <https://service.segway.com/us-en/> to access versions of additional languages (available in English, Spanish, Chinese, Russian, Yiddish, Bangla, Korean, Haitian Creole, Italian, Arabic, Polish, French and Urdu) about important safety information related to battery charging, storage, maintenance, and more.




EN_Contents

Welcome	02
Packing List	03
Diagram	04
Installation and Usage	04
How to Charge	07
Caution	08
Specifications	09
Mark Explanation	10
Trademark	10
EU DECLARATION OF CONFORMITY	11
Certifications	12
Warranty	13

Welcome

Segway 36 V External Battery significantly extends your range, allowing you to ride longer without worrying about charging.



⚠️ Note:


External battery can only be charged when it is installed onto the vehicle. DO NOT charge it separately, otherwise it will lead to insufficient vehicle power, failure of waterproofing, etc.

Before using the external battery, please update the firmware to the latest version.


The pictures shown are for illustrations purposes only. The actual product may vary.

Packing List

- ① External Battery ×1
- ② Fixing Clamps ×2



①



②

● Accessories


- ① M6*25 mm Hex Socket Head Cap Screw × 4
- ② M4*16 mm Pan Head Screw with Flat Washer × 2
- ③ 5 mm(3/16") Allen Wrench × 1
- ④ 2.5 mm(3/32") Allen Wrench × 1
- ⑤ 3 mm(7/64") Allen Wrench × 1
- ⑥ Handle × 1



①



②




③



④



⑤




⑥

Diagram

● External Battery

- ① DC Connector
- ② Charging Port
- ③ Battery Level Indicator



Installation and Usage





Scan the QR code
to watch the
installation video

● Installation

○ E3 & E3 Pro



Step 1

Unscrew 2 screws on the middle position of stem with the 3 mm(7/64") Allen wrench, then fold the vehicle.




Step 2

As shown in the picture, hold the external battery with one hand and slide it along the stem to insert the 2 dowel pins on the back of the external battery and into the 2 screw holes on the stem.




Step 3

As shown in the picture, tighten 4 M6 screws with the 5 mm (3/16") Allen wrench to attach the external battery on the stem through the clamps.




Note: Pre-tighten the 4 screws in order, then fully tighten them alternately and symmetrically.

Step 4
Open the charging port cover of the vehicle, unscrew 2 screws with the 2.5 mm (3/32") Allen wrench, then remove the charging port.



Step 5
Plug the DC connector of the external battery into the charging port of the vehicle, then use the 3 mm (7/64") Allen wrench to tighten the 2 M4*16 mm pan head screws with the spring washer alternately.

Note: Confirm that the DC port has been fully plugged in before tightening the screws.




Step 6
Unfold the vehicle after installation.




* After installing the external battery properly, the external battery icon  on dashboard will light up when powering on.

● Installation of Handle


Step 1
As shown in the picture, after installing the external battery, insert the two straps in its designated position before unfolding the vehicle.



Step 2
Wrap the straps around the stem, first passing them through slot A and then through slot B. Then, pull the straps to ensure they tightly wrap the stem.



Step 3
Wrap the remaining straps around the stem again according to the Step 1, and insert them into slot A to complete the installation.



How to Charge



Before the first use after installation, please charge in accordance with the following instructions until both the external battery and vehicle are fully charged.

The external battery cannot replace the internal battery of the vehicle! When the internal battery level is low, the external battery will automatically begin charging it first.

After a long period of riding in high temperatures, the battery temperature may be overheated. The acceleration, max. speed, and slope climbing performance may be affected.

When the external battery level is lower than 10%, the battery level indicator will flash red.

Note: External battery can only be charged when it is installed onto the vehicle. DO NOT charge it separately.

Connect the DC connector of vehicle's original charger to the external battery's charging port to charge the external battery and vehicle simultaneously.

Note: When charging the external battery, the four beads of the battery level indicator will light up green one by one. The four beads of the indicator will all light up green when the battery is fully charged, and the lights will turn off after 5 minutes.



Cautions

1. Do not dismantle, open or shred secondary cells or batteries.
2. Keep batteries out of the reach of children. Battery use by children should be supervised. Keep small children away from batteries. In particular, keep small parts away from young children.
3. Seek medical advice immediately if a cell or a battery has been swallowed.
4. Do not expose cells or batteries to heat or fire. Avoid storage in direct sunlight.
5. Do not short-circuit a cell or a battery. Do not store cells or batteries haphazardly in a box or drawer where they may short-circuit each other or be short-circuited by other metal objects.
6. Do not remove a cell or battery from its original packaging required for use.
7. Do not subject cells or batteries to mechanical shock.
8. In the event of a cell leaking, do not allow the liquid to come in contact with your skin or eyes. If contact occurs, wash the affected area thoroughly with plenty of water and seek medical attention.
9. Do not use any charger other than that specifically provided for use with the equipment.
10. Observe the plus (+) and minus (–) marks on the cell, battery and equipment and ensure correct use.
11. Do not use any cell or battery which is not designed for use with the equipment.
12. Do not mix different manufacturers' cells or different capacities, sizes, or types within a device.
13. Always purchase the battery recommended by the device manufacturer for the equipment.
14. Keep cells and batteries clean and dry.
15. Wipe the cell or battery terminals with a clean dry cloth if they become dirty.
16. Secondary cells and batteries need to be charged before use. Always use the correct charger and refer to the manufacturer's instructions or equipment manual for proper charging instructions.
17. Do not leave the battery connected to the charger for extended periods when it is not in use.
18. After extended periods of storage, it may be necessary to charge and discharge the cells or batteries several times to obtain maximum performance.
19. Retain the original product instructions or User Manual for future reference.
20. Use the cell or battery only in the application for which it was intended.
21. Dispose of properly.
22. When the vehicle is operated between –5°C and 2°C (23°F and 35.6°F), the internal battery's consumption rate may exceed that of the external battery due to low-temperature limitations. When the temperature drops below –5°C (23°F), the external battery will stop functioning, while the vehicle itself will continue to operate normally (the vehicle can function properly at temperatures down to –10°C (14°F)). No user action is required, and the external battery will automatically resume normal operation once temperatures rise.
23. Stay safe during installation, use the tools correctly, take good security measures, and complete the installation in accordance with the instructions in the user manual.
24. Contact official customer service when necessary.

Specifications

Segway 36 V External Battery	
Model	NZJF3605A(PH1105)
Compatible Charger Models	NBW41D001D7D
Compatible Vehicle Models	E3、E3 Pro
Item Dimensions	339.1 × 110.1 × 92.2 mm (13.35 × 4.33 × 3.63 in)
Net Weight	Approx. 2.5 kg (5.5 lbs)
Gross Weight	Approx. 3.47 kg (7.65 lbs)
Nominal Capacity	5.1 Ah
Nominal Energy	184 Wh
Nominal Voltage	36 V
Charging Limit Voltage	42 V
Operating Temperature	–5°C—40°C (23°F—104°F)
Storage Temperature	–20°C—50°C (–4°F—122°F)

Charging Duration		
Vehicle Model	Charging Facilities	Charging Duration*
E3	Inbox Charger	Approx. 9 h
E3 Pro		Approx. 10.5 h
*The charging duration is measured from the condition when both the vehicle's built-in battery and external battery are fully depleted.		

Range Comparison*			
Eco Mode			
Model	Version	Default Range	with External Battery
E3	U version	Approx. 45 km (28 miles)	Approx. 70 km (43.5 miles)
	E version		
	D version		
	APAC version		
E3 Pro	U version	Approx. 55 km (34 miles)	Approx. 80 km (49.7 miles)
	E version		
	D version		
	APAC version		

Sport Mode			
Model	Version	Default Range	with External Battery
E3	U version	Approx. 20 km (12.5 miles)	Approx. 33 km (20.5 miles)
	E version	Approx. 30 km (18.5 miles)	Approx. 48 km (29.8 miles)
	D version	Approx. 37 km (23 miles)	Approx. 57 km (35.4 miles)
	APAC version	Approx. 30 km (18.5 miles)	Approx. 48 km (29.8 miles)
E3 Pro	U version	Approx. 28 km (17.5 miles)	Approx. 41 km (25.5 miles)
	E version	Approx. 40 km (25 miles)	Approx. 58 km (36 miles)
	D version	Approx. 47 km (29 miles)	Approx. 67 km (41.6 miles)
	APAC version	Approx. 40 km (25 miles)	Approx. 58 km (36 miles)
* Riding with a fully charged new battery, a load of 75±5 kg (165±11 lbs), ambient temperature of 25±5°C (77±9°F), wind speed ≤3 m/s, atmospheric pressure of 86–106 kPa, on a flat paved surface while maintaining full throttle in Eco and Sport mode until the battery is depleted and the vehicle can no longer be operated. * The range may vary depending on multiple factors, including load, ambient temperature, road conditions, speed, tire pressure, and riding habits (frequency of acceleration/deceleration, activation of energy recovery function, etc.). Actual range will differ based on specific riding conditions.			

Mark Explanation

	CE Certification		UL certification
	Battery recycling (for the US)		Separate collection for all batteries and accumulators
			GOST certification in Russia

Trademark

Segway and Rider Design are trademarks of Segway Inc; Ninebot is the trademark of Ninebot (Beijing) Technology Co., Ltd. The respective owners reserve the rights of their trademarks referred to in this manual. We have attempted to include description and instructions for all the functions of Segway 36 V External Battery at the time of printing. However, due to constant improvement of product features and changes of design, your product may differ slightly from the one shown in this document.

©2025 Segway-Ninebot. All rights reserved.

EU DECLARATION OF CONFORMITY

Manufacturer

Name: Ninebot (Changzhou) Tech Co., Ltd.
Address: 16F-17F, Block A, Building 3, NO 18 Changwu Mid Rd, Wujin Dist., Changzhou, Jiangsu, China
Email address: support-eu@segway.eu.com

Authorized Representative

Name: Segway-Ninebot Europe
Address: Dynamostraat 7, 1014 BN Amsterdam, The Netherlands
Email address: support-eu@segway.eu.com

Object of the declaration

Battery Category: Light means of transport batteries (LMT batteries)
Product name: LI-ION BATTERY PACK
Type/model: NZJF3605A
Serial number: Z06B x yyyy x yyyyyy
(“x” indicates any letter from A-Z except O and I, “y” indicates any letter from A-Z except O and I or any number from 0–9)
Specifications: 36 V, 5100 mAh
Label:



This Declaration of Conformity is issued under the sole responsibility of the manufacturer. The object of the declaration described above is in conformity with the following EU Directives:

- EU Battery Regulation: (EU) 2023/1542

Conformity with these Directives has been assessed for this product by demonstrating compliance to the following harmonized standards and/ or technical specifications:

EN 62133-2:2017+AMD1:2021

Signed for and on behalf of: Ninebot (Changzhou) Tech Co., Ltd.

Place: Amsterdam, The Netherlands

Date: October 24, 2025

Name: Andreina Marques

Function: Product Compliance Manager

Signature: Andreina Marques

Certifications

The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012
Ninebot (Changzhou) Tech Co., Ltd. hereby declares the whole product including parts (cables, cords, and so on) meets the requirements of The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012.

Battery recycling information for Users



This symbol means that batteries and accumulators, at their end-of-life, should not be mixed with unsorted municipal waste. Your participation is an important part of the effort to minimize the impact of batteries and accumulators on the environment and on human health. For proper recycling you can return this product or the batteries or accumulators it contains to your supplier or to a designated collection point.

Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling.

Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.

there are separate collection systems for used batteries and accumulators.

Please, dispose of batteries and accumulators correctly at your local community waste collection/recycling center.



EU Authorised Representative:

Segway-Ninebot Europe

Dynamostraat 7, 1014 BN Amsterdam, The Netherlands.

Ninebot (Changzhou) Tech Co., td. hereby declares that the product model: NZJF3605A(PH1105) comply with the EU Battery Regulation: (EU) 2023/1542

The declaration of conformity can be viewed at the following address: www.segway.com

Warranty

We offer warranty service for Segway 36 V External Battery purchased directly from Segway official on-line store and authorized channels. In each case, the warranty period is measured starting on the date of purchase by the original consumer purchaser. The sales receipt from the first consumer purchase, is required in order to establish the start date of the warranty period. Please visit our official website in your region at below links to find more about the Limited Warranty and Dispute Resolution Agreement.

THIS LIMITED WARRANTY DOES NOT IN ANY WAY AFFECT OR LIMIT THE STATUTORY RIGHTS YOU MAY HAVE AS A CONSUMER

Customer Services

For product issues, please contact Segway online customer service or send your requests via e-mail, Segway's support personnel are available to assist you.

Segway Online Services Link: <https://service.segway.com/>

Customer Support E-mail Address:

The Americas: technicalsupport@segway.com

ASIA-PACIFIC, MIDDLE EAST & CIS: service@ninebot.com

Europe: support-eu@segway.eu.com